

TORREXX Electrical Matrix

MODEL		TX-25		TX-50		TX-100		TX-160		TX-240		TX-320	
		KW	AMPS	KW	AMPS	KW	AMPS	KW	AMPS	KW	AMPS	KW	AMPS
VOLTAGE	PHASE												
120	1	3.9	32.5										
208	1	2.9	14.1	5.9	28.1	11.7	56.2						
	3				16.3		32.5	17.8	49.6				
220	1	3.3	14.9	6.5	29.7	13.1	59.5						
	3				17.2		34.4	20	52.4				
240	1	3.9	16.2	7.8	32.4	13	54						
	3				18.8	15.6	37.5	21.5	51.9				
380	3			6.5	9.9	13.1	19.9	20	30.3	29.8	45.4	39.3	59.7
400	3			7.2	10.4	14.4	20.8	20	28.9	33	48	36.6	52.8
415	3			7.7	10.8	15.6	21.7	21.5	30	35.6	50	39.5	55
440	3					13.1	17.2	20	26.2	30	39.4	39.4	51.7
480	3					15.6	18.8	21.5	26	35.6	43	39.5	47.5
575	3											39.2	39.4